

DISKINTERFACE HS MINI INSTRUCTIONS

How to place different loggers models on the DiskInterface HS MINI

DISKINTERFACE HS MINI



DISKINTERFACE HS MINI AND ITS DEVICES




Never make
the logger touch
this part


STERILDISK



STERILDISK PROBE



PASTEURDISK CAN STERILDISK CAN



P-MICRO S-MICRO

USB connection

